




ASSEMBLY INSTRUCTION




PARTS LIST

							
A X 1pc	B X 1pc	C X 2pcs	D X 1pc	E X 1pc	F X 1pc	G X 2pcs	H X 3pcs
							
I X 6pcs	J X 6pcs	K X 12pcs	L X 16pcs	M X 1pc	N X 4pcs	O X 6pcs	


STEP 1




STEP 2




STEP 3




STEP 4




STEP 5




STEP 6




STEP 7




STEP 8




STEP 9




STEP 10




STEP 11




STEP 12




STEP 13





STEP 14



STEP 15



STEP 16



- | | | |
|--------------------|--------------------------|---|
| 1. Volume up | 2. Volume down | 3. Power on/off & External Ambient Light Switch / Ambient Light Mode Adjustment |
| 4. previous track | 5. Pause / Play | 6. next track |
| 7. Type-C charging | 8. hable Type-C charging | 9. Pocket wireless charger |

De tailed Functi on Intr oduct ion

1. Volume Up: Long press / Single tap to increase volume.
2. V olume Dow n: Lon g press/Single tap to decrease volume.
3. Power On/Off Button: Touch and hold to turn on/off the device / Single tap to switch on/off the external ambient light / Switch ambient light mode.
4. Previous Track: Single tap to go to the previous track.
5. Pause Mode: When the device is playing music, it will pause the playback.
6. Next Track: Single tap to go to the next track.
7. Type-C Charging: Insert the Type-C data cable to connect the phone and start charging.
8. Stretchable Type-C Charging: Supports PD protocol. Pull out the stretchable cable to connect the phone and start charging, pull out the cable and it will automatically return to its original position.