


Installation and operation manual of floor lamp

Installation method:

1. Twist the lamp post 3 into the tooth post joint on the lamp post 4.
2. Tighten and fix the lamp pole 123 connection.
3. Remove the plastic ring from the lamp cap and tighten the E27 hole in the middle of the lamp cap with the plastic ring.
- 4 arranged



Installation Notes:

1. This luminaire is suitable for 110 Foshan 240 v power supply, lamp power ≤ 60 W
2. Please wear gloves to avoid scratching the surface of the lamp.
3. Do not install on the wet floor. The environment should be ventilated and dry. LUMINAIRES shall not be near acids, alkalis containing corrosive chemicals and gases, shall not be cleaned with clean water, feather lampshades shall be swept with a feather duster, and the lamp body shall be rubbed with a soft cloth. Should be installed by a professional electrician
6. Switch off the power supply before cleaning and changing the light bulb