




















PARTS LIST

A	2×	B	2×
			
C	2×	F2	2×
			
G2	2×	H2	1×
			
I	1×	J	2×
		 Long	
K2	2×	L	2×
		 Short	


M3	14×	N3	2×		
					
O	8×	P	1×		
 M6×55		 M6×50			
Q	10×	R	10×		
 M6×35		 M6×15			
S	8×	T	8×		
 M8×20					
U	1×	W	28×	X	4×
 M4					

EXPLOSION VIEW




ASSEMBLY


Before your installation, please make sure that you have all the parts listed on the manual. If you find something missing, please stop assembling and contact your supplier immediately.




2




3




4




5




6




7




8




9



10



11



12

Notice: Pay attention to the direction of the buckles(W).
The convex side of the buckle faces into the bar(F2/G2).

